



CHRYSMETAL OOD



МАГНИТНИ НИВОМЕРИ ROCHESTER MAGNETIC LEVEL GAUGES ROCHESTER

За монтаж на цилиндрични или сферични резервоари. Показва процентно съдържание.
Mounted on cylindrical or spherical tanks. Show volume in percentage.

С индикаторен циферблат 50мм			
With indicator dial 50mm - Type SENIOR			
Код Code	Резервоар D Tank Diam. mm	Стебло, Stem, length, mm	Позиция Position
195000	751 - 900	420	TOP
195001	901 - 1050	614	TOP
195002	1051 - 1250	633	TOP
195003	1251 - 1500	900	TOP
195004	1501 - 1750	1050	TOP
1950041	1501 - 1750	1040	TOP
1950042	1501 - 1750	1400	TOP
195005	1751 - 2000	1250	TOP
1950051	1751 - 2000	1600	TOP
1950052	1751 - 2000	1850	TOP
1950053	1751 - 2000	1210	TOP
195006	2001 - 2250	1150	TOP
195007	2251 - 2500	1800	TOP
195900	751 - 900		SIDE/END
195901	901 - 1050		SIDE/END
195902	1051 - 1250		SIDE/END
195903	1251 - 1500		SIDE/END
195904	1501 - 1750		SIDE/END
195905	1751 - 2000		SIDE/END

С индикаторен циферблат 40мм			
With indicator dial 40mm - Type JUNIOR			
Код Code	Резервоар D Tank Diam. mm	Стебло, Stem, length, mm	Позиция Position
194397	751 - 900	420	TOP
194398	901 - 1050	520	TOP
194399	1051 - 1250	620	TOP
1943991	1051 - 1250	850	TOP
1943992	1051 - 1250	645	TOP
194300	1251 - 1500	900	TOP
194301	1501 - 1750	1050	TOP
1943011	1501 - 1750	1000	TOP
194302	1751 - 2000	1250	TOP
1943021	1751 - 2000	1270	TOP
196300	751 - 900		SIDE/END
196301	901 - 1050		SIDE/END
196302	1051 - 1250		SIDE/END
196303	1251 - 1500		SIDE/END
196304	1501 - 1750		SIDE/END
196305	1751 - 2000		SIDE/END



Трансмитер ROCHESTER	Трансмитер ROCHESTER
<i>Hall Effect Twinsite Transmitter 6320S92072E for SENIOR Gauges</i>	<i>Hall Effect Twinsite Transmitter 6320S82072E for JUNIOR Gauges</i>
Код - Code	Код - Code
196071	196065